hidro conta

WATER METERS

fenix

TERT

• hidro conta

www.hidroconta.com

Certification

Potable water



Al rights reserved. © Copyright. 2016 HIDROCONTA. S.A.

WHEN WATER COUNTS

rev: 7

• hidro conta

FENIX WATER METER



WHEN WATER COUNTS

• hidro conta



Dimensions

Calibre		h	н	L	D	Weight with Coupling	Weight with Coupling	Material
mm	Inch		mm			Kg		
13	1/2"	28	130	115	97	0,66	G 7/8" x 3/4"	Composite
15	1/2"	28	130	115	97	0,64	G 3/4"	Composite
13	1/2"	28	114	115	84	1,24	G 7/8" x 3/4"	Brass
15	1/2"	28	114	115 /165	84	1,20	G 3/4"	Brass
20	3/4"	55	130	190	90	1,30	G 1"	Brass
25	1"	50	140	260	103	2,50	G 1 1/4"	Brass
32	1-1/4"	60	158	260	140	4,34	G 1 1/2"	Brass
40	1-1/2"	70	181	300	170	6,72	G2"	Brass





Technical specifications

Cal	libre	Q4	Q₃	Q ₂	Q ₁	Starting Flow Rate	Minimum Reading	Maximum Reading	Ratio	Body Marterial
mm	Inch	m ³ /h				l/h	m ³			
13	1/2"	3,125	2,5	0.013	0,008	1	0,00002	99 999	315	Composite
15	1/2"	3,125	2,5	0.013	0,008	1	0,00002	99 999	315	Composite
13	1/2"	3,125	2,5	0,010	0,006	1	0,00002	99 999	400	Brass
15	1/2"	3,125	2,5	0,010	0,006	1	0,00002	99 999	400	Brass
20	3/4"	5	4	0,016	0,010	2	0,00002	99 999	400	Brass
25	1"	7,875	6,3	0,032	0,020	5	0,00002	99 999	315	Brass
32	1-1/4"	12,5	10	0,064	0,040	10	0,00002	99 999	250	Brass
40	1-1/2"	20	16	0,102	0,064	20	0,00002	99 999	250	Brass

Al rights reserved. © Copyright. 2016 HIDROCONTA. S.A.

• hidroconta



Working conditions

Maximum pressure

≤ 16 bar

Room temperature

0.1 °C ~ 50 °C



Maximum permissible error

Range	Error (%)
$Q_1 \le Q \le Q_2$	± 5%
$Q_2 \le Q \le Q_4$	± 2%



Pressure loss curve





Flow error curve



Al rights reserved. © Copyright. 2016 HIDROCONTA. S.A.

WHEN WATER COUNTS

• hidroconta

FENIX WATER METER

Installation instructions

- The meters must always be full of water when operating, minimum presure 0,3 bar, and installed below the slope of the rest of the pipeline. This stops air pockets from forming inside.

- If there is air in the pipeline, suckers must be fitted to avoid incorrect readings. If the water in the pipeline contains large suspended particles, an initial screening filter should be installed. - Fit a valve upstream from the meter to facilitate maintenance or repair.

- A new pipeline should be drained before fitting a meter to eliminate particles.

- Do not force the meter during assembly; avoid tension or torsional stress, especially to the threaded connections.



1- Which is the difference between dry dial, wet dial and semi-dry water meter dial?

On water meters with dry dial the reading mechanism (clock) is tightly separated from the wet chamber of the meter.

On Wet dial water meter the watch is totally immersed in the fluid.

For water meters with semi-dry dial, the reading mechanism is totally immersed in the fluid but the dial is partially serrated and protected by a sealed capsule.

2- What are the ranges of measurement and precision?

The measuring range of the meters is determined by the Directive MID 2014/32 / UE establishing the ratio between the value of the permanent flow (Q3) and that of the minimum flow (Q1). The water meter can measure up to the maximum flow rate (Q4) for short periods of time without deterioration. The maximum permissible error, positive or negative, in volumes between the transition flow (Q2) (included) and the overload flow (Q4) would be 2% with a water temperature \leq 30 ° C. The maximum permissible error, positive or negative, in volumes between the minimum flow rate (Q1) and the transition flow (Q2) (excluded) would be 5%.

3- The MID directive and its compliance

The MID Directive (2014/32 / EU Measuring Instruments Directive) is a directive of the European Union whose purpose is to harmonize the different aspects of Legal Metrology in the member states. The most important aspect of this directive is that equipment in possession of a MID certificate can be used in the EU.

Al rights reserved. © Copyright. 2016 HIDROCONTA. S.A.

WHEN WATER COUNTS



FENIX WATER METER

WHEN WATER COUNTS CUANDO EL AGUA ES LO QUE CUENTA

www.hidroconta.com

Ctra. Sta Catalina, 60 Murcia (30012) España

T: +34 968 26 77 88 F: +34 968 34 11 49

hidroconta@hidroconta.com

